

Welcome to **MatiGard™**Air

Quick Guide

Designed for home and business security.
Easy to setup and use with Magictrl™.


Getting Started	P2
Start Using the Mobile Client, Magictrl™	P3
Pairing Accessories	P4
Daily Operations	P5
FAQ	P7
Sensor Placement Diagram	P8

Getting Started

Insert SIM Card and Power Cable

On the back of the panel, open the battery cover, you will see a slot for your SIM Card. Insert the Sim Card and connect the power cable.


Power Outlet ←



→ SIM Card Slot

Power ON

2



Flip the switch on the back of the panel to the ON position. Replace the battery cover. Wait 20 seconds as the system runs a start-up diagnostic. You will hear a confirmation when the test is complete. When you see the screen above the system is ready.

- MatiGard™ Air supports GSM based SIM cards. Make sure PIN-codes and voicemail are de-activated on the SIM before use with the panel.
- Make a note of the SIM telephone number, you will need it for setup.


Start Using the Mobile Client, Magictrol™

Download & Setup

1. Visit <http://din.bz/m> or scan the QR-Code to the right.
2. Run the App and follow the on-screen instructions.
3. In the **App Setting** under **Emergency Contacts**, setup the phone numbers to receive phone call and SMS in the event of an alarm.




iOS & Android supported



- You will need an iPhone® or Android™ phone to use the MatiGard™.
- Default Admin Password: 123456 Default User Password: 1234

Pairing Accessories




MatiGard™ uses a new pairing technology called **non-trigger**.

1. Press + button to scan the QR-Code/barcode on the accessory to pair the sensor with the panel.
2. Name the sensor and save the setting to complete pairing.
3. The system will send out a pairing request and you will receive a confirmed text.
4. If needed, you can always modify or delete accessories here.





- MatiGard™ only supports the Dinsafe™ accessories.
- IP Camera and some other accessories use a QR code for pairing. Please keep them intact.

Daily Operations • Main Panel



Control Button

Power Light & Delay Arming Button

- * Press  to enter the settings menu.
- * Press  to navigate.
- * Press  to select.
- * Press  to go back.


- * Power Light with Logo.
- * Long-press to activate delayed Arming.


5

Delayed Arming means the system will wait a few seconds before going into ARM status. This allows you to leave your home without triggering the alarm. The delay time can be adjusted in the Magictrl™.

Child Lock



Lock: Long-press  for 6 seconds until the lock icon shows on screen.

Unlock: Long-press  for 6 seconds until the lock icon disappears.


Knock over to trigger SOS



When an emergency occurs, just knock over the panel, the system will trigger an Emergency Alarm immediately.

The MatiGard™ uses MicroUSB as the power cable interface.
You can easily recharge it via any MicroUSB cable.

Daily Operations · Magictrl™ & Remote Controller



Arming Status Controller

- ARM: All sensors can trigger an alarm
- DISARM: All sensor are deactivated
- HOME ARM: Only chosen sensors can trigger an alarm

Monitor

Monitor • Calls MatiGard™ to listen in through the panel's built-in microphone.

SOS

SOS • Immediately triggers the siren and calls/SMS to all stored emergency contacts.

Accessories

Accessories

- Manage all accessories, like pairing or modifying.

Settings

Settings


- Setting parameters of your MatiGard™.

Device Info

Device Info

- Hardware information of MatiGard™.

6



When you trigger the SOS or any sensor triggers an alarm, all the emergency contacts will receive calls/SMS.

During the call, the following options are available: (Note: If you do not enter the instruction to cancel the Alarm, the panel will call the next emergency contact.)

[]** Press star button twice to monitor.

[##] Press hash button twice to cancel SOS.

[88] Press eight button twice to listen again.

Hang up to call the next emergency contact.

1. Can I use non-Dinsafe™ branded accessories with the MatiGard™?

Sorry, MatiGard™ only supports the Dinsafe™ accessories.

1. The Dinsafe™ accessories use encrypted communication protocols with patented technology. This makes them safer and more stable.

2. The Dinsafe™ accessories are easily paired with the system just by scanning QR codes or Bar codes. All of our accessories support low-battery warning.

Non-Dinsafe™ branded accessories might in some cases be able to pair with the MatiGard™, but stability cannot be guaranteed. We highly advise against using non-Dinsafe™ branded accessories.

2. How can I get help with my MatiGard™ system.

1. Contact the local agency first to get the fastest support service.

2. Visit www.dinsafe.com and submit your question, or send us an email to support@dinsafe.com

3. Why I can't receive auth-code while using my MatiGard™ system the first time?

1. Make sure the SIM Card is installed and activated properly.

2. Make a phone call to your MatiGard™ to check if the SIM Card is installed properly.

3. Make sure the correct country code and telephone number were programmed into the panel.

Default Administrator Password = 123456 Default User Password = 1234

4. How can I reset my MatiGard™ system?


(If you lose your phone or get a new telephone number)

1. Power up your MatiGard™ panel.

2. Hold down the Reset button on the back of the panel until you hear 1 beep.


3. Continue holding the button for 6 seconds and you will hear 2 beeps.

4. The system is now Reset.



Sensor Placement Diagram

8





<http://din.bz/m>



Dinsafe™, MatiGard™, Magictrl™ are trademarks of Dinsafe Ltd. ©2014. All rights reserved.

Website : www.dinsafe.com E-mail : info@dinsafe.com

